

EIB-slave

Slavemodul for Glamox Heating serie 3001
Regulated by 3,5-5 Volt.



ATTENTION!

Make sure that product is disconnected from electrical circuit before replacing the thermostat.

EIB-slave module for Glamox heating.

EIB-slave module for Glamox heating appliances may be controlled by the universal interface US/U 2.2 (two channels) and US/U 4.2 (four channels). When a signal voltage in the range of 3,5-5 volt is applied to the EIB-slave input wire, the heater will switch on and will continue to heat as long as the signal voltage is present.

The US/U 2.2 and US/U 4.2 device is usually regulated by a room thermostat.

